



1. Insert the number of spacers required between the anti-derailleur and the frame. Tighten the 3 screws in steps to 6Nm.
2. Unscrew the small M4 screw (a) by one turn only, then completely unscrew the M5 screw from the fork (b) to rotate the cover.
3. Mount the crankset following the manufacturer's instructions. Place the chain around the chainring.
4. Close the fork by tightening the 2 screws of the cover.
5. Adjust the height of the fork according to the chainring size. Find the right angular adjustment according to the bike geometry.
6. Check that the chain does not touch the fork when passing all speeds. If this is the case, remove or add spacers.

### Warning

Do not use shorter screws. If you wish to replace the screws, please contact your Cydonia dealer.

### Warranty

All Cydonia components are warranted 1 (one) year from the date of purchase against defects in workmanship and materials. This warranty is limited to the first purchaser.

Proof of purchase is required. The product must be returned to its place of purchase or to us directly to process any warranty claim. This warranty does not cover defects resulting from improper or abusive use, modification, lack of preventive maintenance or routine maintenance or failure to comply with assembly instructions and appropriate procedures, wear parts, and products used in competition or for commercial purposes. No compensation can be claimed as damages for any reason. The guarantee does not cover the de-colorization of the colors.



[www.cydonia-bicycles.com](http://www.cydonia-bicycles.com)