



1. Place the Lock-On collar on the grip, with the screw head on rider direction.
2. Make sure the handlebar does not have any grease then slip the grip on it until the grip is flush with the edge of the bar. A rotational movement around the bar or a bit of soapy water in the grip will make the insertion easier.
3. Place the cap while holding the grip.
4. Tighten the Lock-On clamp screw until the grip can not rotate, then tighten the cap screw without excess.